



LOW HEADROOM QUICK CLOSE KIT

- HEADROOM REQUIREMENT:
 - TORSION SPRING: 9" MINIMUM
- NOTE:
 - DOOR WILL HANG DOWN SLIGHTLY INTO THE OPENING.
- INSTALLATION:
 - A - CUT 3" MAXIMUM FROM VERTICAL TRACK.
 - B - INSERT ONE ROLLER IN EITHER HOLE A OR B AND ONE ROLLER IN EITHER HOLE C OR D. FIND THE RIGHT COMBINATION OF ROLLER LOCATIONS THAT WILL ALLOW THE QUICK FLEX DEVICE TO MOVE SMOOTHLY THROUGH THE RADIUS AND STILL ALLOW SECURE END TO BE ATTACHED AS CLOSE TO THE TOP OF THE DOOR AS POSSIBLE.

PARTS LIST

- 2 - QUICK FLEX DEVICES
- 4 - 1/4" X 7/8" LAG SCREWS
- 2 - ROLLERS
- 2 - TRACK EXTENSIONS

SECTION VIEW

SCALE: NTS



MANUFACTURING PLANT & HEAD OFFICE
 13504 ST. ALBERT TRAIL, EDMONTON,
 AB. T5L4P4, PHONE 780-453-3761